

How to install a Custom Length Clothesline

Step 1

Mount brackets



Step 2

Insert the bars into position



Step 3

Connect the cord



Step 4

Ready for use



How to make it Disappear

Step 1

Remove first bar from bracket by pushing bar outwards with one hand while lifting with other



Step 2

Remove the second bar by lifting it out of the other bracket



Step 3

Hold both bars together with one hand, then grab all lines in other hand, and wrap lines around bars



Step 4

Store away in washing basket or laundry cupboard. Stogage Bag is now available

