

# TRAVELLER Removal

**VERSALINE**

disappearing clotheslines  
VERSALINE.COM.AU



Unclip spreader bar from the arm supports



Break down the spreader bar segments



Lift off one arm and, with the cord stretched, rotate arm 180° then walk towards other arm



Insert the arm ends into their mating recesses in the arm base section and lock them together



Remove assembly and, grabbing the cord together, wrap around the arms, then tuck between arms to stop unravelling



Store the juxtaposed assembly along with the spreader bar segments in the carry bag



Store away in an accessible area



Clip covers onto the remaining wall plates

**REPLACING THE TRAVELLER** Just reverse the above steps